

Mobile capture device – Set up instructions

Step 1:

Double check all screw connections.



Step 2:

Fit your mobile phone into the holder and adjust it by moving forward/backward or rotating the holder to make sure the camera is in the centre of the rubber pad.



Step 3:

Unscrew the four screws on the rubber pad and cut a hole for the phone camera. Check to make sure it lines up with the Camera once it's in the holder and then screw the top rubber back.

